

Room Controller and Smart Devices use Click & Go technology:

The Room Controller will automtically recognize any smart device connected with the quick connect cable (provided) and start working immediately upon power up with no processor and a multiple.

The Room Controller defaults to Manual On/Automatic Off vacancy sensor mode for maximum energy savings. Wallstations buttons can toggle zones or trigger preset scenes and can be mixed within each wallstation. ROOM CONTROLLER WIRING DIAGRAM

LIGHTING CONTROLS
Receptacle Control



		,				
DRAWN:M.A.L	DATE: 8/16/14	PROJ:				
CH*KD: X.X.	SCALE: NTS			П		
			-	-	-	-
		DWG #:	-	Τ-	-	-
			-	Τ-	-	-
		F2	-	-	-	1
			-	-	-	-
			DATE	REV	DESCRIPTION	BY
					REVISION TABLE	