



Even though the Occupancy Sensors are shared each Room Controller can have Independent Daylight Sensors and Wallstations for small control zones.



The Room Controller will automatically recognize any smart device connected with the quick connect cable (provided) and start working immediately upon power up with no programming required. The Room Controller defaults to Manual On/Automatic Off vacancy sensor mode for maximum energy savings. Wallstations buttons can toggle zones or trigger preset scenes and can be mixed within each wallstation.

**TITLE:** LIGHTING CONTROLS  
Multiple Occupancy Sensors



|               |               |           |      |     |             |       |
|---------------|---------------|-----------|------|-----|-------------|-------|
| DRAWN: M.A.L. | DATE: 8/16/14 | PROJ:     |      |     |             |       |
| CHK'D: X.X.   | SCALE: NTS    |           |      |     |             |       |
| APPR: X.X.    | SHEET: 1/1    | DWG #:    |      |     |             |       |
|               |               | <b>E3</b> |      |     |             |       |
|               |               |           |      |     |             |       |
|               |               |           |      |     |             |       |
|               |               |           |      |     |             |       |
|               |               |           |      |     |             |       |
|               |               |           |      |     |             |       |
|               | SIZE:         |           | DATE | REV | DESCRIPTION | BY    |
|               |               |           |      |     | PROPORTION  | SCALE |