


Even though the Occupancy Sensor Is shared each Room Controller can have independent Daylight Sensors and Wallstations for small control zones.



Room Controller and Smart Devices use Click & Go technology.
The Room Controller will automatically recognize any smart device connected with the quick connect cable (provided) and start working immediately upon power up with no programming required.
The Room Controller defaults to Manual On/Automatic Off vacancy sensor mode for maximum energy savings. Wallstation's buttons can toggle zones or trigger preset scenes and can be mixed with each wallstation.

ROOM CONTROLLER WIRING DIAGRAM	TITLE: LIGHTING CONTROLS One Occupancy Sensor Multiple RCs
-----------------------------------	---

[illegible]